

DOWNLOAD SOFTWARE AT
ERASEM.COM



EK1001
MECHANICAL KEYBOARD

Standard Functions

Reset to factory default settings: **FN+ ESC**
Backlight on/off: **FN+ Scroll Lock**
Windows/App key lock/unlock: **FN+ Win**


System Requirements:

Windows XP/Vista/7/8/10

Specifications:

104 keys, doubleshot keycaps
Size: 465 x 151 x 33mm. Weight: 1245g
Switch Life: 50M individual presses
Current: 300mA @ 5V

Volume / brightness dial
(push to toggle)



FN+F1 Media Player
FN+F2 Search
FN+F3 Favourites
FN+F4 Mute
FN+F5 Stop
FN+F6 Prev Track
FN+F7 Play/Pause
FN+F8 Next Track
FN+F9 Email
FN+F10 Browser
FN+F11 My Computer
FN+F12 Calculator

Light effect mode sequence - Press FN+INS to cycle between modes

<p>1 - Rainbow Flow Direction (L/R): FN+ ←/→ Speed (1-5): FN+ ↑/↓</p> <p>ANIMATION</p>	<p>2 - Uniform Colour Cycle Speed (1-5): FN+ ↑/↓</p> <p>ANIMATION</p>	<p>3 - Rainedrops Colour: FN+ DEL Speed (1-5): FN+ ↑/↓</p> <p>ANIMATION</p>	<p>4 - Keypress Waves Colour: FN+ DEL Speed (1-5): FN+ ↑/↓</p> <p>REACTIVE</p>	<p>5 - Rainbow Flow 2 Direction (L/R): FN+ ←/→ Speed (1-5): FN+ ↑/↓</p> <p>ANIMATION</p>	<p>6 - Vortex Colour: FN+ DEL Direction (L/R): FN+ ←/→ Speed (1-5): FN+ ↑/↓</p> <p>ANIMATION</p>
<p>7 - Uniform Static Colour Colour: FN+ DEL Speed (1-5): FN+ ↑/↓</p> <p>STATIC</p>	<p>8 - Breathing Colour: FN+ DEL Speed (1-5): FN+ ↑/↓</p> <p>ANIMATION</p>	<p>9 - Tennis Colour: FN+ DEL Speed (1-5): FN+ ↑/↓</p> <p>ANIMATION</p>	<p>10 - Light in the Dark Colour: FN+ DEL Speed (1-5): FN+ ↑/↓</p> <p>REACTIVE</p>	<p>11 - Twinkling Stars Colour: FN+ DEL Speed (1-5): FN+ ↑/↓</p> <p>ANIMATION</p>	<p>12 - Laser Colour: FN+ DEL Speed (1-5): FN+ ↑/↓</p> <p>REACTIVE</p>

Preset Key Colours

There are 5 key colour presets, press **FN+ 1-5** to load a key colour preset. To edit the presets, please see the section "Editing Preset Key Colours" for more information. Standard presets are listed below.

Standard Preset Key Colours:

FN+ 1: FPS - First Person Shooter Game. Keys highlighted: W A S D ↑ ↓ ← → ESC
FN+ 2: CF - Crossfire. Keys highlighted:
W A S D LCtrl LShift LAlt Space R G Q E B 1-5 Tab F1-F3 HM END PU PD PS
FN+ 3: COD - Call of Duty. Keys highlighted: Q W E R T A S D F G C V 1-7 LCtrl LShift
FN+ 4: LOL - League of Legends. Keys highlighted: Q W E R A S D F 1-7
FN+ 5: RACE - QQRace Racing. Keys highlighted: WASDR LCtrl LAlt LShift ↑ ↓ ← →

Editing Preset Key Colours

1. Press **FN+ PrSc** to enter recording mode.
2. The numbers 1-5 will flash red, which represents the different preset numbers. Press the key which represents the preset that you wish to edit.
3. Pressing keys on the keyboard will cycle their colours, the colour that the key is glowing will be the colour that is saved.
4. Press **FN+ PrSc** when finished, to save the settings.
5. To load your preset at a later time, press **FN+ 1-5**. For example if you edited profile 3, then press **FN+3** to load it.

Light Bar Settings

FN+ HM Wave, Neon, Static, Breathing Colour (1-7)
FN+ END Brightness (1-5)
FN+ PU Speed (1-5)
FN+ PD Wave Direction
FN+ Pause Pause Wave
FN+ APP Movement